


INSTRUCTIONS

086082

Directional Relocation Kit



ITEM	DESCRIPTION
1	Butt splice wire connector, 18-22 ga. (4) [not shown]
2	Hole plug, rubber (2)
3	Rear directional studs (2)
4	Jam nut (2)
5	Washer, nylon (2)
6	Hole plug, chrome (2) [not shown]
7	Spacer
8**	Washer (2), 5/16 x 11/16 x 1/16
9**	Locknut (2), 5/16-18

**Items 8 and 9 are used on FLSTF and FLSTS only.